

The Piece Pod 2

Thank you for purchasing a Piece Pod.

With a little care you will get many years of dependable service from it.
The bracket is constructed of laser cut heavy gauge 304 stainless steel.

Parts list:

- Piece Pod 2
- (8) Dual Lock Pads
- This instruction sheet

Installation Instructions:

Installation

- Pick your location
- Position the Piece Pod
- Wipe the bottom of the Pod with Alcohol and let dry
- Place four of the dual Lock Pads on the bottom corners
- Wipe the surface where you want to mount the Pod with Alcohol and let dry.
- Lock the four extra pads to the four on the bottom of the Pod.
- Remove the release film, and then press the pod in place.

Maintenance

- No Routine maintenance, other than cleaning.
- You never need to paint your Piece Pod, but if you want a color to match your locale, the pod can be painted.
- If painting clean and degrease the pod and mask off the hinges and Dual Lock pads. You may need a primer or bonding layer. Check the directions for the type of paint you plan to use.

Cautions

- Always use eye protection when using tools.

Removal

- Remove any items you have stored in the pod.
- Hold the base, not the HTR and tip to a side and pull.

Visit www.Dynapod.com for more information or to order more of our fine products
You can also find information about new products and handy application notes.



FAR Laboratories
P.O. Box 25
South Hadley, MA 01075
800-336-9054, Fax 413-467-9393
Western Massachusetts 413-467-9262